

1.Download APP

Download “My Livoltek” App:

The App is available on Google Play Store(Android) and App Store(IOS).

You can scan the QR code to download it on your phone.



2.Communicate with your inverter via APP

STEP 1
Open the App and enter the homepage.
Click 'Local mode'.

STEP 2
Click 'BlueTooth Mode' in the list.
Click 'Local mode'.

STEP 3
Choose your advice.
(A few tail numbers of SN are device's name.)

STEP 4
Enter your device status page.
Click the '...' icon

Settings page
Now, you can set initial parameters here.

3.Initial parameter Settings

1 Network configurations

Before you connect with Wi-Fi, make sure your inverter has been turned on.

The LED light at the bottom of the inverter will turn green after you configure network successfully.

Enter the wireless network name & password.
Click on "Confirm" and wait for about 10S.

2 Date&Time (Basic Settings > Date&Time)

The date and time of device is synchronized with phone by default.

It can also be set by yourself.

3 Battery Type (Basic Settings > Battery Type)

You would select battery Type here.

You should select Lithium or Lead Acid, and the lithium brand must have been compatible with Livoltek.

4 Work mode (Basic Settings > Work mode)

There are two modes provided for you to choose: Back up, Economic.

Back Up: Battery works as backup supply, which always being charged to full capacity when grid is normal, only discharging when it is grid outage..

Economic: Battery works as normal supply, will adjust the charging and discharging status automatically, optimize your system self-use rate.

The Economic Mode is default if you don't set it manually.

5 Advanced Settings (optional)

When the utility grid is unstable or non-standard in the region, the professional personnel can operate it here.

The password is 'hx123456'.
You can set parameters about output frequency, voltage range, connected phase and so on.