

## INSTALLER USER MANUAL

**TIPS:** Please note that only end-users can register your app account by mobile phone, installers please register by Website.

Web link2: <https://evs.livoltex-portal.com/#/> For Asia, Latin American, Australia and others  
Web link1: <https://www.livoltex-portal.com/#/> For Europe, Middle East Regions, Africa

### 1.Download APP

Download "MY LIVOLTEK" app


The app is available on Google Play Store(Android) and App Store(Apple)



### 2. Registration by web & Use by App


#### STEP 1

Open Web to registration  
Tips: Installers need registration by web and use app.



#### STEP 2

Open your app to use  
1)Put in your account and password  
2)Click the login



#### STEP 3


Successful



### 3.Create a site


#### STEP 1

Enter your Login account and password and verification code  
Click on LOGIN




#### STEP 2

1)Click "CREATE A SITE NOW",if you are logging in for the first time  
2)Input your plant information



#### STEP 3

Choose your system type (Mandatory) and PV capacity (Mandatory)  
PV type(Optional) and PV Arrange (Optional)



#### STEP 4


Set time-of-use tariff of your site.

Tips:  
Please fill in the 24 hours's time of use tariff



#### STEP 5

1)Choose end user's registration region  
2)Put in end user's account name in owner box




### 4.Add your device

#### STEP 1

add your device


Click Click add



#### STEP 2

Choose device model

Click to Scan SN number on your device



#### STEP 3

successfully



### 6. Intial parameter settings by local model(Bluetooth)

#### STEP 1


You could click Local mode

#### STEP 2

Click the "BlueTooth Mode"


#### STEP 3

Find your Device 's SN number, and click it.



#### STEP 4

Initial parameter setting



### 7. Wifi dongle connection

#### STEP 1

You could click Local mode and choose BlueTooth mode

#### STEP 2

Choose your device SN number and click it

#### STEP 3

Connect your phone with your home wifi router

#### STEP 4


1)Select network configuration in settings  
2)Fill in the options with your home wifi information

#### STEP 5

1)Click "Confirm"  
2)Set Successfully wait for 15seconds to take effect

#### STEP 6

1)Re-enter Local Model  
2)connect device with bluetooth and check wifi status



### 8. Usage details



In this screen, you will find daily yield, real-time power, daily revenue, total yield, total revenue and self-use ratio of all your sites.




In this screen you will find the following information about the site



In this screen you can find inverter working state. Touch the system units' icons of PV, Grid, Battery and Load on power flow page, you can check generation details

Parameter setting by local mode bluetooth



Parameter setting remotley on line  
In this screen you can find "Basic settings" "data information"

